


### Components and Hardware List



**44468 2-Drawer Nightstand**

<b>Top</b>  <b>A</b> 1pc.	<b>Bottom</b>  <b>B</b> 1pc.	<b>Side frame</b>  <b>C</b> 2 pc.		
<b>Allen Wrench 5mm</b>  <b>D</b> 1pc.	<b>Bolt Ø5/16-18 x 1-1/4" Long</b>  <b>E</b> 12 pcs.	<b>Lock washer Ø5/16" x Ø12 x 3</b>  <b>F</b> 12 pcs.	<b>Flat washer Ø5/16" x Ø19mm x 2</b>  <b>G</b> 12 pcs.	<b>Anti-Tipping Restraint Kit</b>  <b>H</b> 1 pc.

Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. To prevent possible scratches and damage, this furniture should be assembled on a soft surface such as a blanket or carpet.



**Step 1.** Place the Top upside down and open the drawer. It may be necessary to remove the drawer to attach the Side Frames.

**Step 2.** Position and attach the Side Frames (C) to the sides of the Top using the Bolts (E), Spring Washers (F) and Flat Washers (G). Only partially install Bolts until next Step.

**Step 3.** Position and attach the Bottom to the Side Frames using the same Bolts and Washers.

**Step 4:** Tighten all Bolts using the Allen Wrench.

**Step 5.** Set the assembled Night Stand upright and reinstall the Drawers, if they were removed.



**To release drawer slide**

To remove the drawer:


- Pull the drawer fully open so the black latch is visible in the inside channel of the guides.
- Release the latches by simultaneously pushing one lever up and the other down.
- At the same time, pulling the drawer forward until the slides release. If necessary, empty drawer before removing.

To Reinstall Drawer:

- Carefully reinstall the drawer by aligning the channels on the drawer with the ball bearings in the channels of the cabinet members and gently pushing the drawer closed.
- Carefully open the drawer to verify it is working properly.

## Anti-Tip Hardware Installation Instructions

Notice: Riverside Furniture Corp. recommends that steps be taken for certain furniture items to prevent or minimize the risk of tip-over. This furniture is equipped with Tip-over Restraint Hardware for use to minimize this risk, if used. Please follow below installation steps. Riverside Furniture Corp. recommends that parents and guardians periodically visit the U.S. Consumer Product Safety Commission (CPSC) website at <http://www.cpsc.gov/> and stay up to date on all issues related to children's product safety.



1. Temporarily locate the furniture to near it's final location in the room next to a wall. Locate a wall stud behind your furniture and also mark the stud's location on the back of your furniture.
2. Firmly attach one bracket to the stud approximately 2" below the top of the furniture with the **2 inch long** Wood Screws provided. It may be necessary to drill 3/32 dia. pilot holes for the screws.
3. Firmly attach the other bracket onto a solid, structural part on the back of the furniture using the **5/8 inch long** Wood Screws. It may also be necessary to pilot bore for these screws.
4. Move the furniture into its final position, taking care to line up the wall bracket with the furniture bracket. Thread a strap through the bracket as shown in the illustration. Tighten strap until snug but do not over tighten.

**Caution:** Riverside Furniture Corp. assumes no liability for improper installation or excessive loads placed on screws, brackets or straps. Failure to detach this restraint before moving furniture may result in personal injury and property damage.

**Warning:** This tip-over restraint is not to be a substitute for proper adult supervision. Do not allow children to climb on furniture. Items left on top of the TV and furniture, such as toys, remote controls and treats might tempt young children to climb. Push the TV as far back as possible from the front of its stand. Place electrical cords out of a child's reach, and teach children not to play with the cords.