


#50354
Display Cabinet


Warning :

- Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.
- To prevent possible scratches and damage, this furniture must be assembled on a soft surface such as a blanket or carpet.

Components and Hardware List


<p>Glass Shelf</p>  <p>(A) 4 pcs.</p>	<p>Furniture Tipping Restraint Kit</p>  <p>(B) 1 Set.</p>	<p>Screw Driver not included</p> 
--	--	---

STEP 1:




Unscrew to adjust the shelf
frame height

STEP 2: Attach the Glass Shelf



For product and personal safety, a Furniture Tipping Restraint kit has been included with this unit which can help to minimize the risk of the unit accidentally tipping forward, if used and properly installed per the kit manufacturer's instructions.



The light in this cabinet is a very energy efficient Light Emitting Diode (LED) fixture which is engineered to have a normal life expectancy of several years when used in a typical home.

The entire fixture set has been checked at the factory to verify operation. After connecting the power cord to a working electrical wall outlet, if the light fails to operate, the most common problem is probably a loose connection within the wiring. Verify that all wiring connections are secure.

The 'bulb' or LED contained within the fixture is not a replaceable component part within the light fixture. If required the fixture would need to be replaced.

If the light fails to operate after verifying power to the wall receptacle and checking all electrical wiring connections, contact Customer Service.