









Components and Hardware List

<p>Top</p>  <p><b>(A)</b> 1 pc.</p>	<p>Base</p>  <p><b>(B)</b> 1 Set</p>	<p>Strecher</p>  <p><b>(C)</b> 1 pc.</p>	<p>Ø 5/16" x 1" Bolt</p>  <p><b>(D)</b> 16 pcs.</p>
<p>Ø 5/16" (8mm) Flat Washer</p>  <p><b>(E)</b> 16 pcs.</p>	<p>5/16" Spring Washer</p>  <p><b>(F)</b> 16 pcs.</p>	<p>No. 14x15 Spanner</p>  <p><b>(G)</b> 1 pcs.</p>	



# 49750  
Live Edge Dining  
Table

Be sure to check all packing material carefully for all packed , safely in assembly kit pouch.

To prevent possible scratches and damage, this furniture should be assembled on a soft surface such as a blanket or carpet.

