21440 & 21840
Entertainment Console

The drawer insides are
17-1/2 left to right x 15"
front to back x 5-1/4 top to bottom

Behind the uprights
the shelves are
24-1/4 left to right
x 17-1/2 front to back
x 7-3/4 top to bottom

At the front, the shelves are
18" left to right x 19" front to back